



## Premier Health Products

The leading distributor, designer and importer of shiatsu massage chairs utilizing shiatsu massage therapy



Call-1-866-629-7626 

[Home](#)[Shipping](#)[Products](#)[Back  
Education](#)[Warranty](#)[Contact Us](#)

### PHP 2026 – 2027 Footrest recline troubleshooting

For questions, clarifications or assistance call 303-670-8882

*No tools required*

**BEFORE BEGINNING**, turn the power switch on the chair off and unplug the power cord . Allow the chair to sit for 10 minutes before proceeding.

Lock the leg rest assembly up. This will allow increased access to the working area



Lift the leg rest up and, while holding it up.....

...use your left hand to push the locking mechanism (square tubing) up. Release your hold on the leg rest assembly. The entire assembly should remain up for better access to the work area.




(After completion of the entire task, lower the leg-rest by simply lifting the entire assembly up which will automatically release the lock).

Locate the 3" x 4" expansion board cover and remove it.



Locate the recline and footrest connectors below. Recline in red, footrest in white



1.

Disconnect both the footrest motor and recline motor connectors and swap them. Plug the white into red and then the red into white.

2.

This will reverse the controls on the remote so the footrest buttons will control recline and the recline buttons will control the footrest.

3.

Operate both sets of buttons noting whether or not the motors work properly.

4.

Reconnect the connector wires to their appropriately colored plugs.

5.

Plug chair back in.

6.

Lower footrest by lifting up and lowering.

7.

Test operation of chair.