

# SETUP INSTRUCTIONS


Make sure these 2 connections are secure, Unplug and then plug back in.

## Step 3

- Plug in terminal A to dock A, and terminal C to dock C.
- Please refer to IC board layout below.

### The Layout of IC board:

- Ⓒ Chair back rating, output, AC/DC 110V
- Ⓐ Chair back signal, output, AC/DC 5-12V
- Ⓘ Foot roller, output, DC 12V
- Ⓓ Seat vibrator output DC 12V
- Ⓢ Foot vibrator output 24V
- Ⓛ Footrest lifting motor, output, 24V (Optional)
- Ⓜ Reclining motor, output, 24V



## Step 4

- The power supplier is located at the left rear bottom of the chair. If the chair doesn't work, please check whether the wires are connected well, or whether the fuse is broken. If every thing is fine but the chair still doesn't work, please DO NOT repair by yourself, and contact the company's maintenance department immediately.

