

SAFETY PRECAUTIONS



7. *DO NOT* use the chair under dirty, greasy, smoggy or humid environment.
8. *DO NOT* expose the chair directly to the sun and *DO NOT* place the chair neighbouring to other electric appliances.
9. *DO NOT* clean the chair with alcoholic or evaporative solutions in order to protect the fabric or leather cover.
10. *STOP* using the chair and *UNPLUG* the power cord if the leather or fabric cover is torn or worn-out and causes exposure of the mechanism. Contact our maintenance service immediately for help.
11. Users with hair pomade, please place a towel under their heads, in order to protect the leather or fabric cover.
12. *DO NOT* load two persons on the chair at the same time.
13. People under the age of 16 is suggested not to use the chair.
14. People weigh over 260 pound is restricted to use the chair.
15. *DO NOT* drink or eat during massage.
16. People who are drunk, *DO NOT* use the chair.
17. It is suggested to turn off the chair after been operated for 4 hours, also every user shall take a short break after a 15 minute massage.

CAUTIONS FOR THE BACK WARMER

- 1. To prevent any burns, DO NOT be barebacked when using the warmer.***
- 2 · To prevent any burns, children, disabled people, and persons who are sense-retarded. DO NOT use the function of fixed-point warmer.***
- 3 · DO NOT use the warmer for more than 30 Minutes. Please turn off the warmer for a few minutes before using it again.***

Continuously using the warmer may result in overheating and burns.
- 4 · Turn off the warmer BEFORE shutting down the power of the chair.***

PRODUCT SPECIFICATIONS

Product Name : PREMIER Dual Kneading Air Massage Chair

Model Number : PHP-2027

Voltage : AC 110-120v/60Hz

Consumption : 7W-175W

Timer Range : 5-30 minutes

Lying Angle : 125-175 degrees

Measurement : 40x35x41 inch

Weight : 198lbs