



## Premier Health Products

The leading distributor, designer and importer of shiatsu massage chairs utilizing shiatsu massage therapy



Call-1-866-629-7626 

[Home](#)[Shipping](#)[Products](#)[Back  
Education](#)[Warranty](#)[Contact Us](#)

### PHP 2026

#### Replace the remote control cable

For questions, clarifications or assistance call 303-670-8882

#### *Tools required*

One # 2 Phillips screwdriver, medium length  
Wire cutters.

See steps 1-12 and 15 in [Main PCB assembly replacement](#), first.

***BEFORE BEGINNING***, turn the power switch on the chair off and unplug the power cord . Allow the chair to sit for 10 minutes before proceeding.

#### STEP 1

- 1) Perform steps 1-12 & 15 in [Main PCB assembly replacement](#) then:
- 2) Find the plug on the main PCB where the remote cable plugs in and disconnect it.



3) Cut zip ties securing the wire, being careful not to cut into any of the other wires coming from the board assembly.

4) Fold the wires coming out of the plug back onto themselves tightly.



5) Feed the wire through the notch in the back of the board assembly.



6) Reverse the procedure to reinstall the new cable.

*If after reassembly, and during the final 5-minute test, you detect anything that seems inconsistent with normal operation of the chair, call Premier Health Products Customer Support at 303-670-8882 for immediate assistance.*