

How TO USE

Step 3 Ic Connection



3. Open the small lid above the circuits box by a wrench which is consloed in the bag of operation manual. The IC board is visible after the lid is taken off.

Plug in Terminal A to dock A, and terminal C to dock C. Please refer to IC layout in Step 4.

Step 4 Ic Layout

Make sure these 2 connections are secure, Unplug and then plug back in.

Layout of IC board:

- Ⓐ Chair back rating, output, AC/DC 110V
- Ⓒ Chair back signal, output, AC/DC 5-12V
- ⑨ Foot roller, output, DC110V (Optional)
- ④ Seat roller, output 12V (Optional)
- ⑤ Foot roller, output 12V (Optional)
- ① Footrest lifting motor, output, 24V (Optional)
- ② Reclining motor, output, 24V

